



OLS200

Optical Light Source

User Guide _ Version 1.0

Ascentac
www.ascentac.com

T +886-7-398-1000

F +886-7-398-3965

Copyright

© Copyright 2024 Ascentac. All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior permission of Ascentac.

Disclaimer

Ascentac shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this user guide.

The material in this document is subject to change without notice. For the latest information regarding this product, please visit our website at <http://www.ascentac.com>.

All other trademarks and registered trademarks which appear herein are for reference purposes only and are the property of their respective owners.

Warranty

Ascentac warrants the product against defects in material and workmanship within (1) year from the date of delivery. Under normal use and service, the product will be free from physical defects in material and workmanship during the warranty period, or the product will be repaired or replaced as determined solely by Ascentac.

During the warranty period, you and Ascentac will pay the shipping costs for repairing products for one time respectively. Products returned without proof of purchase or with warranty expired will be repaired or replaced by Ascentac's decision. You shall pay the charges, including maintenance cost, shipping, insurance, duties, taxes, import fees or others which may be caused.

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state and country to country. Because of individual state and country regulations, some of the above limitations and exclusions may not apply to you.

If any of the following conditions take place, the warranty shall be null and void.

- Defects or malfunction caused by human factors, accident, improper use not conforming to product manual instructions, abuse or unauthorized alteration, modification or repair of the product.
- The label with S/N has been altered or damaged.

Notice: Ascentac makes no warranty of any kind with regard to the content in this document, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Service & Support

If you have any questions or need any assistance, please contact our service center.

TEL: +886-7-398-1000

FAX: +886-7-398-3965

Address: 9F.-6, No. 12, Fuxing 4th Rd., Qianzhen Dist., Kaohsiung City 806611, Taiwan (R.O.C.)

Please prepare the following information before you contact us and describe the problems.

- Product model and S/N
- Warranty information


Content

1. Safety Information	1
2. Introduction.....	2
2.1 Features	3
2.2 Application.....	3
3. Layout.....	4
3.1 Appearance	4
3.2 Instruction	5
3.3 LED Indicator	6
4. Display	7
4.1 Optical Light Source (OLS)	7
4.2 Visual Fault Locator (VFL) (Option)	7
5. Operation.....	8
5.1 Power-on	8
5.2 Power-off	8
5.3 Laser-on	8
5.4 Laser-off	9
5.5 Setting Wavelength	9
5.6 Setting Modulation Output	10
5.7 Device Setting	11
5.7.1 Date.....	11
5.7.2 Time	12
5.7.3 Power Saving (Default: 10 mins)	13
5.7.4 Screen Saving (Default: 5 mins).....	14

5.7.5	Brightness (Default: Mid)	15
5.7.6	Battery Charge (Default: OFF)	16
5.7.7	Device Info.....	17

1. Safety Information

Read all safety information carefully before using this product to ensure personal safety and proper use.

- Assure the power supply conforming to the specification of this product and qualified for the country of use.
- Use batteries that meet the specifications of this product.
- Do not use damaged power cords, accessories or other peripheral equipment.
- Make sure the product is operated on the permitted ambient conditions.
- Never directly look into the optical outputs interface.
- Dangerous laser radiation: 

2. Introduction

Ascentac OLS200 Series, Optical Light Source, provides highly stable output power. It is available in a choice of wavelength, including 850nm & 1300nm for multi-mode and 1310nm, 1490nm, 1550nm & 1625nm for single-mode. Customers can select two wavelengths at most in one unit. Its tone generation includes CW (Continuous Wave) and modulated tones at 270Hz, 1kHz, 2kHz.

Ascentac OLS200 Series can be used in conjunction with Ascentac OPM120 Series to provide accurate optical loss measurements. It enables Ascentac OPM120 Series to automatically switch to the proper calibration parameter. The feature reduces the time for communication between two technicians and decreases the possibility of errors.

Ascentac OLS200 Series with low battery indicator can be powered by dry batteries or rechargeable batteries. It also has functions of auto shutdown and backlight sleep mode to extend the battery running time.

2.1 Features

- Two wavelengths at most in one unit
- CW(Continuous Wave) or modulated tones at 270Hz, 1kHz or 2kHz
- Auto shutdown & backlight sleep mode for extending the battery life (Programmable)
- Option: Function of Visual Fault Locator with CW (Continuous Wavelength) or modulated tones at 1Hz or 2Hz

2.2 Application

- Fiber identification
- Performing with Optical Power Meter to measure the loss of optical fiber


3. Layout

3.1 Appearance

- Front






- Side



- Back



3.2 Instruction

Button	Function	Description
	Power on/off	Long press for two seconds to turn on/off the meter.
	Wavelength selection	Short press to switch wavelength.
	Laser on/off	Long press for two seconds to turn on/off the laser.
	Setting	Short press to access device setting.


Item	Function	Description
1	USB	1. Power supply 2. Charge rechargeable batteries
2	OLS optical connector	Built-in universal 2.5mm tip sleeve Option: SC, FC or LC
3	VFL optical connector	Universal 2.5mm
4	Battery	Dry batteries or rechargeable batteries (Charged by USB connection): AAA-size x 4

3.3 LED Indicator


Item	LED Indicator	LED Status	Description
1	PASS/FAIL	Off	X
2	LASER	Off	No emitting light
		Red	Emitting light

4. Display

4.1 Optical Light Source (OLS)





4.2 Visual Fault Locator (VFL) (Option)




5. Operation

5.1 Power-on

Press [] key for two seconds to turn on the meter.
Startup screen → Enter into optical light source interface.



Note

“  ” refers to no emitting light.


5.2 Power-off


Press [] key for two seconds to turn off the meter.

Note


Please turn off laser before you turn off the meter.


5.3 Laser-on

Long press [] key for two seconds to turn on laser.





5.4 Laser-off

Long press [] key for two seconds to turn off laser.




5.5 Setting Wavelength

Short press [] key to switch wavelength.




Note

Wavelength can also be switched by short pressing [] key when laser is off.

5.6 Setting Modulation Output


Short press [**CW**] key repeatedly until the desired modulation output is displayed.




Note

1. Modulation output can also be switched by short pressing [**CW**] key when laser is off.
2. Modulation output:
 - 650nm: CW → 1Hz → 2Hz → CW
 - Other wavelengths: CW → 270Hz → 1kHz → 2kHz → CW


5.7 Device Setting

Short press [] key to access setting as below image.




5.7.1 Date

1. Press [↑] [↓] to move to "Date" and press [↵] to access year setting.
2. Press [↑] [↓] to select year and press [↵] to access month setting; press [ESC] to discard change and return to the original display.
3. Press [↑] [↓] to select month and press [↵] to access date setting; press [ESC] to discard change and return to access year setting.
4. Press [↑] [↓] to select date and press [↵] to confirm it; press [ESC] to discard change and return to access month setting.




5.7.2 Time

1. Press [↑] [↓] to move to "Time" and press [↵] to access hour setting.
2. Press [↑] [↓] to select hour and press [↵] to access minute setting; press [ESC] to discard the change and return to the original display.
3. Press [↑] [↓] to select minute and press [↵] to access second setting; press [ESC] to discard the change and return to access hour setting.
4. Press [↑] [↓] to select second and press [↵] to confirm it; press [ESC] to discard change and return to access minute setting. (10 secs/unit)




5.7.3 Power Saving (Default: 10 mins)

1. Press [↑] [↓] to move to "Power Saving" and press [↵] to set time.
2. Press [↑] [↓] to select time (OFF or 10 to 120 mins) (10 mins/interval) and press [↵] to confirm it; press [ESC] to discard the change and return to the original display.




5.7.4 Screen Saving (Default: 5 mins)

1. Press [↑] [↓] to move to "Screen Saving" and press [↵] to access time interval setting.
2. Press [↑] [↓] to select time interval (OFF or 5 to 30 mins) (5 mins/interval) and press [↵] to confirm it; press [ESC] to discard change and return to the original display.




5.7.5 Brightness (Default: Mid)

1. Press [↑] [↓] to move to "Brightness" and press [↵] to access setting.
2. Press [↑] [↓] to select the brightness (High, Mid or Low) and press [↵] to confirm it; press [ESC] to discard the change and return to the original display.



5.7.6 Battery Charge (Default: OFF)

1. Press [↑] [↓] to move to "Battery Charge" and press [↵] to access turning on/off battery charge.
2. Press [↑] [↓] to select turning on/off battery charge and press [↵] to confirm it; press [ESC] to discard the change and return to the original display.



Note

Users are required to confirm whether to turn on battery charge again after the device detects USB connection.

Use Rechargeable Battery ?

> No , Don' t Charge

Yes , Start Carging

5.7.7 Device Info.

Press [↑] [↓] to move to "Device Info" and press [↵] to view device information.

